



* - 127 V
 ** - 230 V

PRICE LIST OF SPARE PARTS

Pos.	Part Number	Description (Q-ty)	Description National Language (Q-ty)	Price, USD
1	S-190	Screw ST5x60 (4)		
2	S-024	Spring washer Ø5 (4)		
3	S-004	Washer Ø5 (4)		
4	M-113	"O"-ring Ø19xØ3		
5	G-052	Gear housing		
6	L-054	Pin Ø5X8		
7	O-073	Friction bearing		
8	S-191	Washer Ø43xØ20x2,5		
9	S-192	Snap ring Ø12		
10	K-077	Spindle		
11	F-053	Gear		
12	S-193	Washer Ø8xØ16x0.5 (2)		
13	M-114	"O"-ring Ø8XØ1.5		
14	N-115	Impact clutch		
15	R-004	Steel ball Ø5 (24)		
16	G-053	Gear housing cover		
17	O-066	Needle bearing HK081210 (2)		
18	J-028	Brush cap (2)		
19*	1D-011	Carbon brush 127V 6x10x13 (2)		
19**	D-011	Carbon brush 230V 6x10x13 (2)		
20	H-109	Handle cover		
21	J-021	Brush holder (2)		
22*	1A-040	Armature 127V		
22**	A-040	Armature 230V		
23	O-002	Ball bearing 608.RS		
24*	1C-015	Swtich 127V		
24**	C-015	Swtich 220V		
25	S-075	Screw ST4x16 (2)		
26**	E-034	Inductor 18µH 230V (2)		
27	J-014	Connektion spring Ø12.5 (2)		
28	R-060	Spring		
29**	E-038	Condenser with plate 0.33µF 230V		
30*	1B-024	Stator 127V		
30**	B-024	Stator 230V		
31	M-002	Cord clip		
32*	1E-002	Cord 127V		
32**	E-002	Cord 220V		
33	M-003	Rubber sleeve		
34	S-111	Circlip for hole Ø28		
35	M-007	Bearing bush Ø25xØ22x9		
36	R-007	Steel ball Ø7.14 (2)		
37*	1T-097	Brand label (2) 127V		
37**	T-097	Brand label (2) 220V		
38	S-085	Screw ST4x55 (2)		
39	H-110	Housing		
40	I-039	Guide wing circle		
41	O-009	Ball bearing 6001.RS		
42	K-078	Gear shaft		
43	M-115	Felt ring Ø23xØ11x3		
44	M-116	Bracket		
45	S-194	Washer Ø8xØ16x3		
46	F-054	Doublel gear		
47	L-055	Pin Ø8x50		
48	M-050	O- ring Ø28xØ2		
49	S-076	Screw ST4x18 (3)		
50	M-117	Gasket		
501	K-079	Impact block		