WS24-230 D





* - 127 V
** - 230 V

DWT Nov 09 ANGLE GRINDER WS24-230D

PRICE LIST OF SPARE PARTS

Pos.	Part Number	Description (Q-ty)	Description National Language (Q-ty)	Price, USD
1	M-094	Outside flange		
2	M-095	Inner flange		
3#	P-012	Wheel guard Ø230 (WS24-230D)		
4	M-079	"O"-Ring		
5	S-055	Screw M8x25		
6	R-017	Key 4x5x13		
7	K-060	Spindle		
8	S-039	Screw M5x16 (4)		
9	S-024	Spring washer Ø5 (4)		
10	G-044	Gear housing cover		
11	O-015	Ball bearing 6202.RS		
12	M-097	Bearing cover Ø28		
13	S-023	Spring washer Ø4(6)		
14	S-100	Screw M4x10(6)		
15	F-042	Big gear(WS24-230D)		
16	S-097	Circlip for shaft Ø15		
17	O-070	Bronze bush Ø16xØ10x10		
18	G-035	Gear housing		
19	S-181	Screw ST5x35 (4)		
20	S-176	"C" ring 6,3		
21	R-076	Brake spring		
22	L-044	Brake pin		
23	S-183	Rubber plunge (2)		
24	Q-041	Side handle		
25	S-179	Lock nut M8x1		
26	F-048	Small gear(WS24-230D)		
27	O-014	Ball bearing 6201.RS		
28*	1A-031	Armature 127V		
28**	A-031	Armature 230V		
29	O-006	Ball bearing 629.RS		
30	M-009	Bearing bush Ø32xØ26x9		
31	I-031	Guide wind circle		
32	S-184	Screw ST5x70 (2)		
33*	1B-030	Stator 127V		
33**	B-030	Stator 230V		
34**	C-023	Soft start 230V		
35	J-015	Connection spring Ø12.5 (2)		
36*	1T-079	Brand label (2) 127 V (WS24-230D)		
36**	T-079	Brand label (2) 230 V (WS24-230D)		
37A	H-083	Handle A		
37B	H-091	Handle B		
38*	1C-018	Switch 127V		
38**	C-018	Switch 230V		
39**	E-006	Condenser 0.33μF 230V		
40	S-074	Screw ST4x14(2)		
41	M-002	Cord clip		
42*	1E-004	Cord 127V		
42**	E-004	Cord 230V		
43	M-004	Rubber sleeve		
44	M-085	Felt ringØ30xØ20x5		
45	S-075	Screw ST4x16 (5)		
46	J-029	Brush cap (2)		
47*	1D-012	Carbon brush (2) 127V		
47**	D-012	Carbon brush (2) 230V		

48	J-023	Brush holder (2)		
49	H-063	Housing		
50	M-098	Bearing cover Ø19,5		
51	N-114	Rotary button		
52	R-077	Spring Ø 6x12		
500	Q-044	Spanner(WS24-230D)		
501	Q-045	Hex.spanner M6		