


Exploded view BHD-800N



Spare parts list BHD-800N

No. Part Name

(10)	Needle bushing HK0709	(49)	Spring
(14)	Needle-roller bearing	(50)	Needle bearing HK0609
(15)	Red button	(51)	Cylindrical gear
(17)	Driver pin	(52)	Needle bearing
(19)	Selector knob	(53)	Drive end shield
(23)	Cylindrical gear	(54)	Needle bushing HK0908
(25)	Clutch disk	(55)	Spring clip
(26)	Ratchet sleeve	(56)	Shift fork
(30)	Impact bolt	(57)	Ball bearing
(31)	Guide bushing	(58)	Toothed shaft
(32)	O-ring 18x3,5	(60)	Ball bearing
(33)	O-ring 10,8x3,6	(63)	Armature
(34)	Damping bushing	(64)	Ball bearing
(36)	Piston	(67)	field
(37)	O-ring	(69)	Rubber bearing sleeve
(38)	Cylinder	(76)	Carbon brush
(44)	Intermediate flange	(77)	Brush spring
(47)	Bushing washer	(78)	Brush holder assy
(48)	Bushing	(80)	Switch
