


---

Exploded view



---

## Parts List

### No. Part Name

- 2 Reciprocating rod assembly
  - 5 Rolling sliding block
  - 7 Eccentric big gear
  - 12 Needle roller sleeve
  - 13 Central support
  - 19 Brush holder
  - 20 Brush copper sleeve
  - 21 Brush assembly
  - 36 Variable speed board
  - 37 Switch
-