

Spare parts list BSM-650U-QK

No.	Part Name
3	Output shaft
6	Bearing 6001-2Z
12	Impact block
13	Bearing 608-2Z
14	Segregation
15	Change plate
16	Impact button
18	Rotor
19	Brush holder cover
20	Carbon Brush
21	Brush holder
22	Bearing 607-2Z
23	Bearing sheath
24	Stator
31	Switch