


Exploded view BBS-801N



Spare parts list BBS-801N

No. Part Name

| | | | |
|----|---------------------------|----|------------------|
| 2 | Big gear | 38 | Speed regular |
| 3 | Ball bearing | 48 | Brush holder |
| 6 | Ball bearing 608RS | 49 | Brush |
| 7 | Aluminum base | 50 | Brush cover grip |
| 14 | Needle bearing | 51 | Switch |
| 15 | Front wheel | 57 | Timing Belt |
| 16 | Front-wheel frame | 58 | Small pulley |
| 22 | Copper sets | 61 | Middle cover |
| 24 | Real wheel shaft | 63 | Bearing 608 RS |
| 26 | Bearing 606 | 64 | Rotor |
| 25 | Real wheel | 66 | Bearing 626 RS |
| 30 | Introduction sets of wind | 67 | Large Pulley |
| 32 | Stator | 68 | Bearing 608 RS |
| 34 | Left housing | 69 | Gear shaft |
