


Exploded view BFB-710N



Spare parts list BFB-710N

No. Part Name

- ④ Driven wheel
 - ⑤ Bearing 608-2z
 - ⑨ Belt
 - ⑫ Bearing 66200z
 - ⑭ Idle wheel
 - ⑳ Blade
 - ㉓ Bearing 628-2z
 - ㉖ Stator
 - ㉗ Rotor
 - ㉙ Switch
 - ㉛ Bearing 626-2z
 - ㉝ Brush support
 - ㉞ Brush holder
 - ㉟ Spring
 - ㊱ Carbon brush
-