


Exploded view BCP-1400N



Spare parts list BCP-1400N

| No. | Part Name |
|-----|-----------------------|
| 5 | Spindle |
| 10 | Front cap |
| 11 | Bearing |
| 13 | Gear |
| 15 | Sleeve Bearing |
| 19 | Stop pin |
| 22 | Bearing |
| 23 | Armature |
| 24 | Bearing |
| 25 | Bearing set |
| 30 | Stator |
| 35 | Brush holder |
| 36 | Brush spring |
| 37 | Brush |
| 41 | Variable speed switch |
| 42 | Switch |
