


# Exploded view BFP-500



---

## Spare parts list BFP-500

No.	Part Name
16	Nozzle
18	O-ring seal
19	Needle valve
29	Switch
32	Motor