


# Exploded view BFB-850-T



---

## Spare parts list BFB-850-T

### No. Part Name

- ⑥ Switch
- ②① Belt driving
- ②② Pulley leading
- ②⑦ Rotor
- ③① Stator
- ③② Brush holder
- ③③ Set of brushes
- ③⑨ Pulley driven
- ④① Base mobile
- ④⑧ Blade body blades
- ⑤⑨ Clutch shaft cutting depth adjustment