


---

# Exploded view BFP-400



---

## Spare parts list BFP-400

No.	Part Name
4	Nozzle
5	O-ring seal
6	Needle valve
19	Motor
20	Switch