


# Exploded view BHG-2000L-K



---

## Spare parts list BHG-2000L-K

No.	Part Name
16	Electric motor
17	Circuit board
22	Switch
30	Heating wire