


Exploded view BAB-18lx2-DK



Spare parts list BAB-18lx2-DK

No.	Part Name
4	Gear box assy
8	Gear motor
10	Electric motor
13	Switch
14	Reversing switch reverse
28	Charger (pos. 26, 27)