


EXPLODED VIEW BCT-170-M



Parts List BCT-170-M

No	Part name
①	Nut collet
②	Collet
⑧	Rotor
⑪	Set of brushes
⑫	Stator
⑭	Adjust speed
⑱	Switch