


# Exploded view DEP-900-R



---

## Spare parts list DEP-900-R

No.	Part Name	No.	Part Name
1	Screw	25	Spring
2	Label	26	Hand wheeling down cover
3	Side cover	27	Degree scale disk
4	Brush box	28	Adjustable spring
5	Carbon brush	29	Front base plate
6	Brush box cover	30	Small steel jacket
7	Right housing	31	Steel ball
8	Cable sheath	32	Small spring
9	Cable	33	Bearing
10	Cable clamp	34	Blade axoplast
11	Capacitance	35	Screw
12	Switch	36	Bar
13	Back base plate	37	Screw
14	Stator	38	Blade
15	Tapping screw	39	Blade washer
16	Bearing	40	Bearing
17	Checking ring	41	Small belt wheel
18	Armature	42	Left housing
19	Tapping screw	43	Bearing
20	Tapping screw	44	Big belt wheel
21	Hand wheeling cover	45	Screw
22	Big washer	46	Leather strap
23	Connect screw	47	Leather strap cover
24	Guard	48	Nameplate