


# Exploded view BAB-12-P



## Parts List BAB-12-P

No	Part name
②5	Motor gear
②8	Motor
③0	Right body
⑤2	Right body
⑤3	Charge base
⑤4	Adapter
⑤5	Gear box assy
⑤6	Battery pack assy
⑤7	Switch assy